


Note:
All relay are reed type



| | | | |
|-------|---|-----------------------------------------|------------------------------|
| Title | | <Title> Low Cost Aircraft Strobe Lights | |
| Size | A | Document Number | Dave Barker 0206 |
| Rev | 0 | Date: | Wednesday, December 27, 2006 |
| Sheet | | 1 | of 1 |

Set Output to +2V

Change Capacitor C1 to 40 uF/350 Volt
Kodak disposable Camera Circuit Board (1 of 3)
Add trigger Reed relay

+2V TO RIGHT STROBE
 +2V TO TAIL STROBE
 +2V TO LEFT STROBE